



F I G. 1




002707 "Eth 506960

F I G. 2A



F I G. 2B



0027007-EH506960

FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7A

SINGLE-PLATE DISC (SUCH AS CD-DA, CD-R,
CD-ROM AND CD-RW)




FIG. 7B

SINGLE-LAYER HD DISC (SINGLE-LAYER DVD)




FIG. 7C

HYBRID DISC (SACD)





FIG. 7D

MULTI-LAYER HD DISC (DUAL-LAYER DVD)



09690543-101700

002707-E1506960




FIG. 8A FIG. 8B FIG. 8C FIG. 8D

01700 9605042101700

FOCUS POSITION DISC SURFACE DISC MIDDLE LEVEL SURFACE

FIG. 9A




FIG. 9B




FIG. 9C




FIG. 9D






FIG. 10



דוחות מ-1870

FIG.11

COMMAND TO RECORD DATA
INTO A MEMORY CARD



F207
PERFORM PROCESSING TO PROHIBIT
A RECORDING OPERATION

FIG.12

SOURCE	PERMISSION OR PROHIBITION OF MEMORY-CARD RECORDING	RECORDING-LAYER STRUCTURE
CD-DA (CD-TEXT, CD-G)	○	
CD-ROM (VIDEO CD)	×	SINGLE-PLATE DISC
CD-RW	×	
CD-R	×	
DVD-ROM	×	SINGLE-LAYER HD DISC OR MULTI-LAYER HD DISC
DVD-R	×	
DVD-RW	×	
SA-CD	ONLY CD LAYER ○	HYBRID DISC
MD-DA (PRE-MASTERED)	○	
MD-DA (RECORDABLE TYPE)	×	
MD-DATA	×	
TUNER	†	×
EXTERNAL INPUT		×
MO DISC		×